IP Camera

IE Browser User Manual

Document Edition:	V1.0
The Manual for:	IP Camera or Module
Date:	Aug 20, 2021

Statement

We make the best to verify the integrity and correctness of the contents in this document, but no formal guarantee shall be provided. Use of this document and the subsequent results shall be entirely on the user's own responsibility. We reserve the right to change the contents of this document without prior notice.

- Design and Specifications are subject to change without prior notice.
- The Contents in this manual may be different from the edition that you are using. Should any unsolved problem occur given that the product is used according to this manual, please contact our technical support department or your product suppliers.
- Note: it's a user's responsibility for the security and any other problems caused by mismanaging a password.

Readership

This manual is suitable for engineers as follow:

- System planning person
- Support and maintenance person
- Administrator
- User

Notes:

- "IP Camera" mentioned in this manual refers to network camera, including box IP camera, dome IP camera, infrared box IP camera, speed dome IP camera, etc.
- Click: Press the left mouse button once.
- Double-click: Press the left mouse button twice.
- If you set or change parameters, please run the browser as an administrator.

Modify record

Recording the corresponding update, the latest document include all of the content in previous editions.

Modify date	Edition	Explanation

Content

Statement	2
Readership	2
Modify record	3
Content	4
1. OVERVIEW	6
2. Recommended PC Specifications	6
3. Login	6
3.1 Install Active	6
3.2 Login	9
4. Preview	0
4.1 Main Menu Bar1	1
4.2 PTZ Control 1	2
4.2 Speed Dome Control1	3
5. Video Playback1	4
5.1 Video Playback	4
5.2 Video Playback & Download1	5
6. Log 1	5
7. Config 1	6
7.1 System	6
7.1.1 Version	6
7.1.2 Time	6
7.1.3 Maintain	7
7.1.4 Config1	8
7.1.5 Serial1	9
7.2 Network1	9
7.2.1 ETH 1	9
7.2.2 Service	0
7.2.3 PPPOE	0
7.2.4 DDNS2	1
7.2.5 FTP	1
7.2.6 EMAIL	2
7.2.7 UPNP	2
7.2.8 CMS	3
7.2.9 ONVIF	3
7.2.10 802.1X	4
7.2.11 AlarmHost2	4
7.3 AV2	4
7.3.1 Encode2	4
7.3.2 ROI	6
7.4 Image2	6
7.4.1 Display2	6
7.4.2 OSD	8

7.4.4 ICR	7.4.3 Video Mask	29
7.4.5 AWB Weight 30 7.4.6 AE Weight 30 7.5 Safe 31 7.5.1 User Manager. 31 7.5.2 Security Config 31 7.6 Event 31 7.6.2 Hoto Detect 33 7.6.3 IO alarm 34 7.6.4 Alarm Out 34 7.6.5 Audio Alarm 34 7.6.6 Abnormal 35 7.6.7 alarm snap 35 7.7.7 Store 36 7.7.1 Record 36 7.7.2 Disk 37 7.7.3 Time Snap 37 7.8 PTZ 38 7.9 Status 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.10 Local 39 7.9.4 Bitrate 39 7.1 Occal 39 7.9.4 Distrates 40 9.1 Video Diagnosis 40 9.1 Video Diagnosis 40 9.1 Scolor Abnormal 41 9.1.2 Sharpness Abnormal 41 9.1.2 Sharpness Abnormal 41 9.1.2 Sharpness Abnormal 41 </td <td>7.4.4 ICR</td> <td>29</td>	7.4.4 ICR	29
7.4.6 AE Weight 30 7.5 Safe 31 7.5.1 User Manager 31 7.5.2 Security Config 31 7.6 Event 31 7.6.1 Motion Detect 31 7.6.2 Hide Detect 33 7.6.3 IO alarm 34 7.6.4 Alarn Out 34 7.6.5 Audio Alarm 34 7.6.6 Abnormal 35 7.7.7 Store 36 7.7.1 Record 36 7.7.2 Disk 37 7.7.3 Time Snap 37 7.8 PTZ 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.9.3 Channel 39 7.9.4 Bitrate 39 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2.2 Warning Area, Object leave, Object lost 42 9.2.2 Warning Are	7.4.5 AWB Weight	
7.5 Safe 31 7.5.1 User Manager 31 7.5.2 Security Config 31 7.6 Event 31 7.6.1 Motion Detect 31 7.6.2 Hide Detect 33 7.6.3 IO alarm 34 7.6.4 Alarm Out 34 7.6.6 Abnormal 34 7.6.7 alarm snap 35 7.6.7 alarm snap 35 7.7.7 Store 36 7.7.2 Disk 37 7.7.3 Time Snap 37 7.8 PTZ 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.9.5 Abnormal 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2.2 Warning Area 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.4 Object Leave	7.4.6 AE Weight	30
7.5.1 User Manager. 31 7.5.2 Security Config. 31 7.6 Event 31 7.6 Event 31 7.6.2 Hide Detect 33 7.6.3 IO alarm 34 7.6.4 Alarn Out 34 7.6.5 Audio Alarm 34 7.6.6 Abnormal 35 7.6.7 alarm snap. 35 7.7 Store 36 7.7.1 Record 36 7.7.2 Disk 37 7.7.3 Time Snap 37 7.7.8 PTZ 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Recode 38 7.9.4 Bitrate 39 7.10 Abormal Brightness 40 9.1 Video Diagnosis 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2.2 Warning Area 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.4 Object Leave 44 9.2.4 Object Leave 44 9.2.4 Object Leave </td <td>7.5 Safe</td> <td>31</td>	7.5 Safe	31
7.5.2 Security Config. 31 7.6 Event 31 7.6.1 Motion Detect 33 7.6.2 Hide Detect 33 7.6.3 IO alarm 34 7.6.4 Alarm Out 34 7.6.5 Audio Alarm 34 7.6.6 Abnormal 34 7.6.7 alarm snap 35 7.6.7 alarm snap 35 7.6.7 alarm snap 36 7.7.5 Store 36 7.7.7 Store 36 7.7.2 Disk 37 7.7.3 Time Snap 37 7.8 PTZ 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.10 Local 39 8. Logout 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness. 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2.2 Warning Area 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.4 Object Leave	7.5.1 User Manager	31
7.6 Event 31 7.6.1 Motion Detect 31 7.6.2 Hide Detect 33 7.6.3 IO alarm 34 7.6.4 Alarm Out 34 7.6.5 Audio Alarm 34 7.6.6 Abnormal 34 7.6.7 alarm snap 35 7.6.7 alarm snap 35 7.6.7 alarm snap 36 7.7.1 Record 36 7.7.3 Time Snap 37 7.8 PTZ 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scne Change 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.4 Object Lost 45 10.4 Derging the Eirmune 45	7.5.2 Security Config	31
7.6.1 Motion Detect 31 7.6.2 Hide Detect 33 7.6.3 IO alarm 34 7.6.4 Alarm Out 34 7.6.5 Audio Alarm 34 7.6.6 Abnormal 35 7.6.7 alarm snap 35 7.6.7 alarm snap 36 7.7.1 Record 36 7.7.2 Disk 37 7.7.3 Time Snap 37 7.7.3 Time Snap 37 7.8 PTZ 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.9.5 August 40 9.1 Video Diagnosis 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 <td>7.6 Event</td> <td>31</td>	7.6 Event	31
7.6.2 Hide Detect. 33 7.6.3 IO alarm 34 7.6.4 Alarm Out 34 7.6.5 Audio Alarm 34 7.6.6 Abnormal 35 7.6.7 alarm snap. 35 7.6.7 alarm snap. 35 7.7 Store 36 7.7.1 Record 36 7.7.2 Disk 37 7.7.3 Time Snap 37 7.7.3 Time Snap 37 7.8 PTZ 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.9.4 Bitrate 39 7.9.4 Bitrate 39 7.9.1 Abnormal Brightness 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.4 Object Leave 44 9.2.4 Object Lost <td>7.6.1 Motion Detect</td> <td>31</td>	7.6.1 Motion Detect	31
7.6.3 IO alarm 34 7.6.4 Alarm Out 34 7.6.5 Audio Alarm 34 7.6.6 Abnormal 35 7.6.7 alarm snap 35 7.6.7 alarm snap 36 7.7.1 Record 36 7.7.1 Record 36 7.7.2 Disk 37 7.7.3 Time Snap 37 7.7.3 Time Snap 37 7.8 PTZ 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2.1 Single cross line 42 9.2.2 Warning Area, Object leave, Object lost 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45	7.6.2 Hide Detect	33
7.6.4 Alarm Out 34 7.6.5 Audio Alarm 34 7.6.6 Abnormal 35 7.6.7 alarm snap 35 7.7 Store 36 7.7.1 Record 36 7.7.2 Disk 37 7.7.3 Time Snap 37 7.8 PTZ 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.10 Local 39 8. Logout 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2.1 Single cross line 42 9.2.2 Warning Area, Object leave, Object lost 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45	7.6.3 IO alarm	
7.6.5 Audio Alarm 34 7.6.6 Abnormal 35 7.6.7 alarm snap 35 7.6.7 alarm snap 35 7.7 Store 36 7.7.1 Record 36 7.7.2 Disk 37 7.7.3 Time Snap 37 7.7.3 Time Snap 37 7.8 PTZ 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout. 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10.4 Ubergrding the Eirmware 45	7.6.4 Alarm Out	
7.6.6 Abnormal 35 7.6.7 alarm snap. 35 7.6.7 alarm snap. 35 7.7 Store 36 7.7.1 Record 36 7.7.2 Disk. 37 7.7.3 Time Snap 37 7.8 PTZ. 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.9.4 Bitrate 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout. 40 9.1 Video Diagnosis 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10.4 Unergrading the Eirmware 45	7.6.5 Audio Alarm	
7.6.7 alarm snap. 35 7.7 Store 36 7.7.1 Record 36 7.7.2 Disk. 37 7.7.3 Time Snap 37 7.8 PTZ 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout. 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10.4 Uperndix 45	7.6.6 Abnormal	35
7.7 Store 36 7.7.1 Record 36 7.7.2 Disk 37 7.7.3 Time Snap 37 7.7.3 Time Snap 37 7.8 PTZ 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout 40 9. Al Functions(Support Module) 40 9. Al Functions(Support Module) 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10.4 Lingrading the Eirmungree 45	7.6.7 alarm snap	35
7.7.1 Record 36 7.7.2 Disk 37 7.7.3 Time Snap 37 7.7.3 Time Snap 37 7.8 PTZ 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2.1 Single cross line 42 9.2.2 Warning Area, Object leave, Object lost 42 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10. Appendix 45	7.7 Store	
7.7.2 Disk	7.7.1 Record	
7.7.3 Time Snap 37 7.8 PTZ 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2.1 Single cross line, Warning Area, Object leave, Object lost 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10. Appendix 45	7.7.2 Disk	
7.8 PTZ 38 7.9 Status 38 7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout 40 9. Al Functions(Support Module) 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.4 Object Lost 45 10. Appendix 45	7.7.3 Time Snap	
7.9 Status 38 7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout 40 9. Al Functions(Support Module) 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10. Appendix 45	7.8 PTZ	
7.9.1 HardWare 38 7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout 40 9. Al Functions(Support Module) 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10. Appendix 45	7.9 Status	
7.9.2 Recode 38 7.9.3 Channel 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout 40 9. Al Functions(Support Module) 40 9.1 Video Diagnosis 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10. Appendix 45	7.9.1 HardWare	
7.9.3 Channel 39 7.9.4 Bitrate 39 7.10 Local 39 8. Logout 40 9. Al Functions(Support Module) 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10. Appendix 45	7.9.2 Recode	
7.9.4 Bitrate 39 7.10 Local 39 8. Logout 40 9. Al Functions(Support Module) 40 9.1 Video Diagnosis 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10. Appendix 45	7.9.3 Channel	39
7.10 Local398. Logout.409. Al Functions(Support Module)409.1 Video Diagnosis409.1.1 Abnormal Brightness.409.1.2 Sharpness Abnormal419.1.3 Color Abnormal419.1.4 Scene Change429.2 Cross line, Warning Area, Object leave, Object lost429.2.1 Single cross line429.2.2 Warning Area449.2.3 Object Leave449.2.4 Object Lost4510. Appendix45	7.9.4 Bitrate	
8. Logout. 40 9. Al Functions(Support Module). 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness. 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10. Appendix 45	7.10 Local	39
9. Al Functions(Support Module) 40 9.1 Video Diagnosis 40 9.1.1 Abnormal Brightness 40 9.1.2 Sharpness Abnormal 41 9.1.3 Color Abnormal 41 9.1.4 Scene Change 42 9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10. Appendix 45	8. Logout	40
9.1 Video Diagnosis409.1.1 Abnormal Brightness409.1.2 Sharpness Abnormal419.1.3 Color Abnormal419.1.4 Scene Change429.2 Cross line, Warning Area, Object leave, Object lost429.2.1 Single cross line429.2.2 Warning Area449.2.3 Object Leave449.2.4 Object Lost4510. Appendix45	9. AI Functions(Support Module)	40
9.1.1 Abnormal Brightness409.1.2 Sharpness Abnormal419.1.3 Color Abnormal419.1.4 Scene Change429.2 Cross line, Warning Area, Object leave, Object lost429.2.1 Single cross line429.2.2 Warning Area449.2.3 Object Leave449.2.4 Object Lost4510. Appendix45	9.1 Video Diagnosis	40
9.1.2 Sharpness Abnormal419.1.3 Color Abnormal419.1.4 Scene Change429.2 Cross line, Warning Area, Object leave, Object lost429.2.1 Single cross line429.2.2 Warning Area449.2.3 Object Leave449.2.4 Object Lost4510. Appendix45	9.1.1 Abnormal Brightness	40
9.1.3 Color Abnormal419.1.4 Scene Change429.2 Cross line, Warning Area, Object leave, Object lost429.2.1 Single cross line429.2.2 Warning Area449.2.3 Object Leave449.2.4 Object Lost4510. Appendix45	9.1.2 Sharpness Abnormal	41
9.1.4 Scene Change429.2 Cross line, Warning Area, Object leave, Object lost429.2.1 Single cross line429.2.2 Warning Area449.2.3 Object Leave449.2.4 Object Lost4510. Appendix45	9.1.3 Color Abnormal	41
9.2 Cross line, Warning Area, Object leave, Object lost 42 9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10. Appendix 45	9.1.4 Scene Change	42
9.2.1 Single cross line 42 9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10. Appendix 45	9.2 Cross line, Warning Area, Object leave, Object lost	42
9.2.2 Warning Area 44 9.2.3 Object Leave 44 9.2.4 Object Lost 45 10. Appendix 45 10.1 Upgrading the Firmware 45	9.2.1 Single cross line	42
9.2.3 Object Leave	9.2.2 Warning Area	44
9.2.4 Object Lost	9.2.3 Object Leave	44
10. Appendix	9.2.4 Object Lost	45
10.1 Upgrading the Eirmware	10. Appendix	45
10.1 Opgrading the Finnware	10.1 Upgrading the Firmware	45
10.2 General Troubleshooting45	10.2 General Troubleshooting	45

1. OVERVIEW

This camera is a megapixel network camera module with a built-in web based viewer accessible by multiple browsers.

This camera supports two compression formats and multiple streaming simultaneously. The two standard compression formats include H.265, H.264 and MJPEG. The streams can be configured to a variety of resolutions, bit rates and frame rates.

NOTE:

The several features are dependent on camera model.

2. Recommended PC Specifications

- CPU: Intel Core 2 Duo 2.4 GHz or higher or Intel Core i5, i7 2.8 GHz or higher
- Resolution: 1280X1024 pixels or higher (32 bit color)
- RAM: 2 GB or more
- Supported OS: Windows Vista (32 bit) Ultimate, Business Edition, Windows 7, 8 (32/64 bit), 10 (32/64 bit) Ultimate, Professional Edition
- Support Browser: Microsoft Internet Explorer Ver. 9.0, 10.0 or Higher, Safari Ver. 4.0 (Plug-in free viewer only), Google Chrome Ver. 4.0 (Plug-in free viewer only)

3. Login

3.1 Install Active

1. Open IE Web browser, input IP address, then pop up login interface:

🚽 😌 🙋 http://192.	168.1.160/login.asp	▼ (3 搜索	÷ ۵	107 27 2	23
WEB SERVICE	×					
*						
		State of the second				
	and the second se					
	User Name	admin	AT.			
	Pass Word					
	Language	English	V			
		Login Cancel	tan di Neti			
	Nata Dia sa	- decombered & involution Arctives	V 6 1			
	Note:Please	e downioad & install the Active.	A TIFST. FILE			

Tips: First time login, please download and install web active.

	1			
	admin	$+ \lambda$		
User Name:	admin	No.	VIII	1
Pass Word:	_		1	
Language:	English		~	$\sim \sim$
				1
Concession in the second second	Login	Cancel		- 1 ()
Note: Please	download & i	nstall the Activ	re K first. <mark>File</mark>	-X

Click "Download address"

A prompt box appears at the bottom of the page, click the [Run(R)]:



Click [Next>]:



Click [I Agree]:



Click[Browse], choose install path, then click [Install]:

1				
noose install Location				-
Choose the folder in which to install H265Active 1.1.18.				U
Setup will install H265Active 1.1.18 in the following folder. Browse and select another folder. Click Install to start the	To install installation	in a differer n.	nt folder,	dick
Destination Folder				
Destination Folder C:\Program Files (x86)\H265Active		Bro	wse	
Destination Folder C:\Program Files (x85)\H265Active Space required: 4.7MB		Bro	wse	
Destination Folder C:\Program Files (x86)\H265Active Space required: 4.7MB Space available: 80.2GB		Bro	wse	

Prompt Complete the H265Active 1.1.18 installation wizard, click the [Finish]:



3.2 Login

After install Active, refresh the IE browser, input the default of IP address, user name, password:

Default Setting:

- IP address: 192.168.1.160
- User name: admin
- Password: 12345



* The user name and password cannot be empty. If one of them is empty, the system will give a corresponding error prompt.

* Camera language default is English, Click language drop-down box can be switch to other languages display.

Click login to enter into main interface.

4. Preview

Login success, turn to "Preview":



In the Live view interface, users can do operations like Snap, Record, Audio, Talk, Clear Alarm, Log Search, Local Zoom of Image, Full-screen Viewing, PTZ and Lens Control.

4.1 Main Menu Bar

This is the main menu bar for the Preview:

0	Snap	Record	Audio	📗 Talk	🖂 Full	6	3D	Fluency	RealTime	<	StreamType	Main	~
---	------	--------	-------	--------	--------	---	----	---------	----------	---	------------	------	---

[Snap]: Capture image and save at local PC, this function should be run with administrator account, default save path: C:\Users\admin\AppData\Local\H265Active\LocalCapture\.

Snap	En Recort 📣 Audio	🎚 Talk	S Full	🗟 зр	Fluency RealTime V	StreamType Main	~
------	-------------------	--------	--------	------	--------------------	-----------------	---

The save path can be modified in the local picture path of "Configuration>Local Configuration", to modify the path, you also need to run as an administrator.

Preview	Playback	Log	Log Conf		Logout
System		Local Config			
NetWork					
AV		Active	X Version	v1.0.14	4
Image		Local Re	cord Path	C:\Use	ers\Administrator\AppData\Local\H265Active\LocalRecord\
Safe		Local Picture Path		C:\Use	ers\Administrator\AppData\Local\H265Active\LocalCapture\
Event		Download Re	cord Path	C:\Use	ers\Administrator\AppData\Local\H265Active\DownloadRecc
Store		Download Pie	cture Path	C:\Use	ers\Administrator\AppData\Local\H265Active\DownloadPictu
Ptz		Tips: Use Admi	nistator t	o excut	ite the browser and to
Status			Mod	ify nath	bl
Local			Hod	ny puti	
				Save	

[Record]: The system will start recording, a flashing will appear in the upper corner

real-time video, indicating that it is recording.

This function needs to run browser as an administrator to save locally. The default save path is: C:\Users\admin\AppData\Local\H265Active\LocalRecord\.

Snap 📷 Record	🚽 Audio	🚺 Talk	🖂 Full	🧟 зD	Fluency RealTime 🗸	StreamType Main 🗸
---------------	---------	--------	--------	------	--------------------	-------------------

The save path can be modified in the local picture path of "Configuration>Local Configuration", to modify the path, you also need to run as an administrator.

Preview	Playback	Log	Con	fig	Logout
System		Local Config			
NetWork					
AV		Active	X Version	v1.0.14	
Image		Local Red	cord Path	C:\User	s\Administrator\AppData\Local\H265Active\LocalRecord\
Safe		Local Pic	ture Path	C:\User	s\Administrator\AppData\Local\H265Active\LocalCapture\
Event		Download Red	cord Path	C:\User	s\Administrator\AppData\Local\H265Active\DownloadReco
Store		Download Pic	ture Path	C:\User	s\Administrator\AppData\Local\H265Active\DownloadPictu
Ptz		Tips: Use Admir	nistator t	o excut	e the browser and to
Status			Mod	if u noth	
Local			Mod	ny patri	1
				Save	

[Audio]: Enable listen for device (camera should support sound input, and the PC need support sound output), double click to stop listen.

💽 Snap 📷 Record 📣 Audio 🖞 Talk 🔝 Full 🧕 3D 🛛 Fluency RealTime 🗸 StreamType Main 🗸

[Talk]: Enable to speak with device (camera and PC should support audio in and audio out), double click to stop voice intercom.

💽 Snap 📷 Record 🌗 Audio 🚺 Talk 🔯 Full 🧕 3D 🛛 Fluency RealTime 🗸 StreamType Main 🗸

[Full]: Switch to full screen preview, double click to exit it. Double click real time video also can switch to full screen preview.

💽 Snap 📷 Record 📣 Audio 🎚 Talk 🔯 Full 🕺 3D 🛛 Fluency RealTime 🗸 StreamType Main 🗸

[3D]: This function for PTZ camera. Enable operate for high speed dome camera. If the product is not PTZ product, no change when you click this buttons on menu)

💽 Snap 📷 Recort 📣 Audio 🖞 Talk 🖾 Full 🙍 3D 🛛 Fluency RealTime 🗸 StreamType Main 🗸

[Fluency]: Set the live preview show mode, optional parameters is RealTime, Fluency, Smooth.

Snap 🔄 Record 🛶 Audio 🕌 Talk 🔀 Full 🧕 3D 🛛 Fluency RealTime 🗸 Stream	ype Main 🗸	~
--	------------	---

[StreamType]: Set the stream type for live preview, optional parameters is Main, Second, Three(Customized).

💽 Snap 📷 Record 🌗 Audio 🖞 Talk 🔯 Full 🧕 3D 🛛 Fluency RealTime 🗸 StreamType Main 🗸

4.2 PTZ Control

[PTZ]: PTZ menu can set the speed dome camera parameters like direction, rotation speed,

zoom+/-, focus+/-, Auto Iris.



4.2 Speed Dome Control

This function is setting for speed dome camera.

[Preset]: Set speed dome preset. Support Preset 1~254.



[Cruise]: Set speed dome cruise. Support Cruise 1~8.

Preset Cruise	Call the selected cruise
+	Stop current running cruise
	Save current running cruise
	Delete the preset in this cruise
	Modify the preset in this cruise

PTZ	Add preset to the current cruise
Add Cruise	Can set preset dwell time and speed
Preset Preset 1 🗸	
Dwell 5	
Speed 1	
OK Cancel	

5. Video Playback

Click[Playback], switch to video Playback page:

Prev	iew Playback	Log	Config	Logout		HD-IP Camera
						Record Search
						Timer record V
						Begin
						End
						2021-11-06 23:59:59
						Search
► II	■ >> <@			0:00:0	0/0:00:00	
No	Туре	BeginTin	ne ~ EndTime	Size	Ctrl	Status
						<u>`</u>
		Total	0 Item Current 0 Item I	First Page Previous Pag	e 0/0 Next Page Las	t Page

Video Playback is valid for support the camera with TF card storage.

5.1 Video Playback

Video can be playback by selected type, the video types are divided into: timed record, Motion detection, Alarm input, Manual record, Tampering, Tampering, Network Down, Sensor, Face detect, Audio detect, Lift stop detect, AVD, PEA OSC, CPC, SMOKE, Lift Abnormal Open, Lift Abnormal Close, Lift Abnormal Run, Lift Maintenance, Lift Fault, All Record.

Default record mode is "Timing Recording". Camera default record time period is 00:00:00-23:59:59.

5.2 Video Playback & Download

Click search, all details will appear at the bottom of the page. Click the [Play] button to play the video.

The control bar can operate video playback, pause, stop, single frame advance, sound and other functions. On the right is the video playback progress display.

Click **[Down]**, to download the video. Video default save at local, when download is finish, it will prompt "download complete", default save path

 $\label{eq:c:Users} C: \label{eq:cond} C: \label{c$



We can modify save path in "Configuration>Local Configuration" to download the video. Modifying the save path requires running the browser as an administrator.

6. Log

Click the [Log] on the toolbar at the top of the main interface to open the log query window.

Prev	iew Playback	Log	Config	Logout			HD-IP Camera
No	Time	Major Type	Minor Type	Channel	User	Remote	
1	2021-11-06/08:52:43	operation	Query Log	0	admin	192.168.1.123	Search
2	2021-11-06/07:40:35	operation	Manual Control Alarm Out	3	admin	192.168.1.123	Major Type
3	2021-11-06/07:40:35	operation	Manual Control Alarm Out	2	admin	192.168.1.123	all
4	2021-11-06/07:40:34	operation	Manual Control Alarm Out	1	admin	192.168.1.123	Minor Type
5	2021-11-06/07:40:33	operation	Manual Control Alarm Out	0	admin	192.168.1.123	Begin
6	2021-11-06/06:23:35	operation	Set time	0	admin	192.168.1.123	2021-11-06 00:00:00
7	2021-11-06/06:23:34	operation	Login	0	admin	192.168.1.123	End
8	2021-11-06/06:23:29	operation	Logout	0		192.168.1.123	2021-11-06 23:59:59
9	2021-11-06/06:22:47	operation	Set time	0	admin	192.168.1.123	
10	2021-11-06/06:22:47	operation	Login	0	admin	192.168.1.123	Search
11	2021-11-06/05:50:05	i system	Start up	0	admin	0.0.0.0	
							3. 4

To query the log, you need to fill in the query conditions, including the log type and time period.

Log types are divided into main types and sub-types.

Major Type: All, system, alarm, operation, network, parameter, Abnormal. Minor Type: Provide the listing for each Major Type. The default time period: 00:00:00-23:59:59.

Click Query, the program will list the logs that meet the conditions in the list box.

7. Config

Config includes10 function parts: System, Network, AU, Image, Safe, Event, Store, PTZ, Status, Local.

Preview P	layback	Log	Conf	ig	Logout		HD-IP Camera			
System NetWork	Versi	on Time	Maintain	Config	Serial	~				
AV Image		Pr	Type oduct Model	IFC		· ·				
Safe		Com	ipany Name							
Event			Our Address							
Store			Serial No	20211028	00001					
PIZ		Softw	are Version	4.2.122						
Local		Software	Issue Date	2021-10-0	1 15:08:31					
Loodi		1	DSP Version	0.0.0.0						
		DSF	Issue Date	Oct 18 202	1 21:48:58					
		Bo	ard Version	0.0.0 ONVIF						
		HardW	are Version	2.0.e3.52).e3.52 Build 012 nor					

7.1 System

7.1.1 Version

This page can query device type, Product Model, Company Name, Our Address, Serial No, software version, Software Issue Date, DSP Version, DSP Issue Date, Board Version, HardWare Version.

7.1.2 Time

Set to enable NTP time calibration, manual time calibration, etc.

Preview Play!	back L	og	Confi	ig	Logout		HD-IP Camera
System	Version	Time	Maintain	Config	Serial		
NetWork							
AV		TimeZon	e (GMT+08:	00) Beijing,	Hongkong, Singapo	re, Taipei 🗸	
Image		ONTP-					
Safe			Server	Address	time.windows.cor	n	
Event				Interval	24	Hour	
Store		Manı	ual				
Ptz		0	Dev	ice Time	2021-11-6/9:7:3	2/8	
Status			Dev	ice mine			
Local				Set Time	2021-11-6 9:7:3	2/8 📃 🗌 Sync Wit	:h PC
		Sync Tin	ne				
		5	Sync Time aft	er Login	\checkmark		
				Save			

[Time zone]: Display device current time zoned and it can be set according to the actual situation.

[NTP]: NTP is a network time protocol. Enter server address, and the device will synchronize with the server time. The server address can be an available Internet time synchronization server address or the IP address of the NVR. The calibration interval is generally 12h or 24h.

[Manual]: Manually modify the time of setting the camera. Check **"Sync with PC**" and click the [Save] button to keep the camera and the local PC host time consistent.

[Sync time]: check "Sync Time after Login", each time the device logs in to the Web client, the device will automatically check the time once.

After the related parameters are modified, please remember to click the [Save] button.

7.1.3 Maintain

On this page, you could Reboot device, Restore, upgrade software firmware, set auto maintain parameter.

Preview	Playback	Log	onfig Lo	gout		HD-IP Camera
System NetWork AV Image Safe Event	Version Rebool Restor Simp	t Reboot Reboot re ble Restore	in Config Ser	ial		
Store Ptz Status	Facto	ory Restore all par	ameter will be set to	factory default		_
Local	Auto R	upgrade file	ay Sunday ne 1:0	→ Brows	e upgrade	
		[Save			

[Reboot]: Click "Reboot" to restart the device

[Restore]: Provide two type to restore. **[Simple Restore]** can save IP, user info. **[Factory Restore]** all parameters will be set to factory default.

[upgrade]: Click "Browse", select local upgrade file, and then click "Upgrade". The upgrade status shows the current upgrade speed. When the upgrade is completed, it will prompt upgrade to be successful.

[Auto Reboot]: choose enable, the device will restart periodically when the maintenance is set.

Warning:

- 1. Update process takes 1~10 minutes, please do not turn off the power.
- 2. Camera will automatically restart after update success, please do not turn off the power.

7.1.4 Config

On this page, you can set the device name, choose language, loop recording, video format, and video output format

Preview	Playback	ck Log		k Log Config Logout				Logout	HD-IP Camera
System		Version	Time	Maintain	Config	Serial			
NetWork									
AV				Name	Camera				
Image				Language	English	~			
Safe			Rec A	uto Recycle	v				
Event				Video Format	PAL	~			
Store			Vide	o Out Mode	cvbs	~			
Ptz					-	1			
Status				10.000	Save	1			
Local									

[Name]: Default is Camera.

[Language]: English/Chinese.

[Rec Auto Recycle]: After the disk is full, it will continue to record from the front overwriting the previously recorded clips.

[Video Format]: PAL/NTSC.

[Video Out Mode]: CVBS.

7.1.5 Serial

Preview	Playback	k Log Cont			Config Logout		HD-IP Camera
System		Version	Time	Maintain	Config	Serial	
NetWork						U	
AV				Serial	Serial 1	~	
Image							
Safe				WorkMode	PTZ Mode	\checkmark	
Event			Bau	udRate(bps)	4800	~	
Store				DataBit	8	~	
Ptz				StopBit	1	~	
Status				FlowType	No	~	
Local				Parity	None	~	
					Save]	

[Serial]: Support 2 serials.

[Working Mode]: 3 Model, includes transparent, PTZ mode, Alarm Box Mode.

[Baud Rate(bps]: 600~115.2k optional.

[DataBit]: 5,6,7 and 8 optional.

[StopBit]: 1 and 2 optional.

[FlowType]: None, Soft Flow Type and Hard Flow Type optional.

[Parity]: None, Odd and Even optional.

7.2 Network

7.2.1 ETH

It will automatically display IP address, subnet mask, gateway, Dns server address and Mac

address camera.

Modify camera IP address of the camera, you need to login with the new IP address to display the monitoring screen.

review	Playback	Log	C	onfig		Logout				l H	ID-IP Can
System	ETH	Service	PPPOE	DDNS	FTP	EMAIL	UPNP	CMS	ONVIF	802.1X	AlarmHost
NetWork		L.				u .			u		u <u> </u>
AV		ETH	1	~							
Image											
Safe		⊖ Aut	to IPv4 Add	r							
Event) Cor	nfig IPv4 Ac	ldr ——							
Store				IPv4 Add	dr 192	2.168.1.160)				
Ptz			IP	/4 Net Mas	sk 255	5.255.255.0)				
Status			IPv	4 Gate Wa	y 192	2.168.1.1					
Local			O DNS Ser	ver							
		() COI	ing Divo Se	DNC	1 8 8	8.8					
				DNS	0.0	4.4				_	
				DNS	0.0	.4.4					
			Mac Add	dr E0:3C	5B:95	:41:83]				
				Save							

7.2.2 Service

The port configure includes four types: [Msg Port]: Message Port. Default is 8080. [Rtsp Port]: Rtsp Port. Default is 554. [Http Port]: Http Port. Default is 80. [Rtmp Port]: Rtmp Port. Default is 1935.

Preview	Playback		Log	С	onfig		Logout			HD-IP			IP Camera		
System		ETH	Service	PPPOE	DDNS	FTP	EMAIL	UPNP	смѕ	ONVIF	802.1X	AlarmHost			
NetWork			1												
AV				Msg Po	ort 8080										
Image				Rtsp Po	ort 554										
Safe				Http Po	ort 80										
Event				Rtmp Po	ort 1935]							
Store				E	Carra										
Ptz					Save										
Status															
Local															

When accessing the device through the network, you can set the corresponding port as needed. After the relevant parameters are modified, click [Save] button to save the settings.

7.2.3 PPPOE

Check "Enable" to enable PPPOE function.

Enter the broadband user name and password provided by the network operator where the device is located, and click **[Save]**.

Unplug the network cable connected to the external network from the WAN port of the switch, insert

it into the LAN port (using the switch as a router), and connect to the device through the router. After dialing is successful, the camera will obtain PPPOE IP address.

Preview	Playback		Log	С	onfig		Logout				l l i	ID-IP C	amera
System		ETH	Service	PPPOE	DDNS	FTP	EMAIL	UPNP	смѕ	ONVIF	802.1X	AlarmHost	
AV				Enab	ole 🗆								
Image				NetCa	rd Ether	net0	~	·					
Safe				Us	er]					
Event				Passwo	rd								
Store				PPPOE	IP 0.0.0	.0							
Ptz					Cause								
Status					Save								
Local													

Note: The default gateway becomes invalid after the PPPOE setting is turn on

7.2.4 DDNS

In the public network environment, the dynamic IP address used by most users .

DDNS (Dynamic Domain Name Resolution) to access the network camera through the domain name, which can effectively solve the problem of not being able to obtain the current dynamic IP to access the camera.

Preview	Playback		Log	с	onfig		Logout				H	ID-IP Came
System		ETH	Service	PPPOE	DDNS	FTP	EMAIL	UPNP	смѕ	ONVIF	802.1X	AlarmHost
NetWork		-			1				U			
AV				Enab	le 🗆							
Image				Provid	er 3322		~	7				
Safe				Nan	ne							
Event				Passwo	rd			1				
Store				Accou	nt]				
Ptz				Po	ort 80]				
Status				Refrech()	н) 2			1				
Local					Save			1				

7.2.5 FTP

By config FTP parameters, you can control the two-way transmission of files on the Internet, and upload camera capture image to FTP server.

review	Playback	.	Log	С	onfig		Logout				H	ID-IP Ca	me
System		ETH	Service	PPPOE	DDNS	FTP	EMAIL	UPNP	CMS	ONVIF	802.1X	AlarmHost	
NetWork													
AV				FTP Serv	rer								
Image				FTP Po	ort 21]					
Safe				Us	er anon	mous		Anon	ymous				
Event				Passwo	••••								
Store				ſ	Dir Seco	nd Level	~	-					
Ptz				First Lev	/el Use D	Device Ip	~						
Status				Second Lev	Use D	Date(Yea	r/Mon/Da 🗸	-]					
Local			Custo	om First Lev	/el]					
			Custom	Second Lev	/el]					
					Save								

7.2.6 EMAIL

Alarm message will sent to your mail when an alarm occurs when you setting e-mail push service. To use this function, you need to enable the POP3/SMTP service in the mailbox that sends the mail. The specific method for opening POP3/SMTP service can be found on the Internet.

review	Playback	Log	C	onfig		Logout				H	ID-IP Cal	mer
System	ET	H Service	PPPOE	DDNS	FTP	EMAIL	UPNP	смѕ	ONVIF	802.1X	AlarmHost	
NetWork												
AV			SMTP Serve	er								
Image			SMTP Po	rt 25			🗌 Enal	ble SSL				
Safe			Use	er]					
Event			Passwoi	rd]					
Store			From Add	dr			1					
Ptz			To Add	-1			1					
Status			To Add	-2			1					
Local			To Add	-3			1					
				Save								

[SMTP Server]: Enter the address and port of the SMTP server. The information can be found on the Internet. For example, the SMTP server address of 163mailbox is: smtp.163.com.

[SMTP Port]: SMTP Port is enabled 25.

[Enable SSL]: Check "Enable SSL", the mail will be sent after SSL encryption.

[User]: Username Fill in the mailbox username.

[Password]: It should be noted that the password here is not the mailbox password, but the client authorization code to open the POP3/SMTP service in the mailbox.

[From Addr]: Fill in the complete email address.

[To Addr1~3]: The receiving address does not need to open the POP3/SMTP service, just a valid mailbox.

7.2.7 UPNP

UPnP protocol is enabled, this function can realize the automatic discovery of the camera in the local area network and the automatic port mapping function of the router.

review	Playback	Log	С	onfig		Logout				H	ID-IP Ca	am
System	ETH	Service	PPPOE	DDNS	FTP	EMAIL	UPNP	смѕ	ONVIF	802.1X	AlarmHost	
AV			Enab	ole 🗆								
Image			NAT Serv	er 0.0.0	.0]					
Safe			NAT Mo	de Auto		~	·					
Event			Refresh(H) 1]					
Store			•					Refresh				
Ptz		enable	po	ort type		external p	ort			state		
Status			msg po	ort	0		N	lot in eff	fect			
Local			rtsp po	ort	0		Ν	lot in eff	fect			
			http po	ort	0		Ν	lot in eff	fect			
			rtmp p	ort	0		N	lot in eff	fect			

The mapping mode can be selected as "fixed mapping" and "automatic mapping". In automatic mode, the camera will automatically communicate with the router to map the external port under the public IP. If the current port has been allocated by the router's UPNP function, the camera will increase the port number by 1 and continue to communicate with the router until it is added 15 times. If the port is still allocated by the router's UPNP function, the camera will no longer perform automatic port mapping. In manual mode, the user can specify the external port for the next public IP mapping, and the user does not need to modify the port of the camera itself. If the router or gateway does not support the UPNP function, the user can fill in the current external port status here.

After the port is mapped, the status bar will display whether it is valid, and the external port under the currently mapped public IP is displayed in the external port. If the user needs to access the camera through the public network, it needs to use the currently mapped external port to access.

7.2.8 CMS

In this page, you could enable central config, set device ID, central server IP, central server port, click save and the setting success, as image below.

Preview	Playback		Log	С	onfig		Logout				H	D-IP Cam	era
System		ETH	Service	PPPOE	DDNS	FTP	EMAIL	UPNP	смѕ	ONVIF	802.1X	AlarmHost	
NetWork		-		L 1	1 1					1			
AV				Enab	ole 🗆								
Image				PU	ID 2021	02800	001]					
Safe				CMS Ho	ost 192.1	68.100	.100]					
Event				CMS Po	ort 8000			1					
Store				Sta	te Conne	ecting	~	1					
Ptz				500									
Status					Save								
Local													

7.2.9 ONVIF

You could enable ONVIF authentication, set ONVIF port, choose to enable ONVIF RTSP authentication and set ONVIF RTSP port

Preview	Playback		Log	С	onfig		Logout				IH:	ID-IP Ca	mera
System	E	тн	Service	PPPOE	DDNS	FTP	EMAIL	UPNP	смѕ	ONVIF	802.1X	AlarmHost	
NetWork		0											
AV			ONVIF A	uthenticati	on 🗹								
Image			ONVI	F Server Po	ort 8000								
Safe		ON	VIF RTSP A	uthenticati	on 🗆								
Event				RTSP Po	ort 8554								
Store		Tips:	: Modify R	TSP Conf	ig, Devic	e will	be REBOO	DT!!					
Ptz			8 (298)288(5)(94)22(22), • 4 (88)	E									
Status					Save								
Local													

Check "ONVIF RTSP authentication", at this time the RTSP request sent to the network camera needs to carry authentication information.

7.2.10 802.1X

Set to enable 802.1X.

review	Playback		Log	С	onfig		Logout				H	D-IP Cam	iera
System		ETH	Service	PPPOE	DDNS	FTP	EMAIL	UPNP	CMS	ONVIF	802.1X	AlarmHost	
NetWork	-	L											
AV			E	nable 802.	1X 🗆								
Image		0		\sim									
Safe			1	Protocol Ty	pe EAP-I	MD5	~	'					
Event				Us	er								
Store				Passwo	rd]					
Ptz					Caula	-							
Status					Save								
Local													

7.2.11 AlarmHost

Set to enable AlarmHost.



7.3 AV

7.3.1 Encode

This page is setting encoding parameters. Switch main stream and sub stream to view the encoding

parameters of the current device.

Preview P	ayback	Log	Config	Logout		HD-IP Camera
System	Encode	ROI				
NetWork			10-			
AV		Ch	nannel Channel	01 🗸		
Image		Stream	n Type Main	~		
Safe						
Event		Frame	e Rate 20		Frame Rate Priority	
Store			GOP 50			
Ptz		Bitrate	(kb/s) 6144			
Status		Reso	olution 1080P(1	920*1080) 🗸		
Local		Stream Mix	Type video str	eam 🗸		
		Encode	Type H.264	~		
		Encode	Level high prot	file 🗸		
		Bitrate	Type CBR	~		
		GOP	Mode SMART	P 🗸		
		Audio Encode	Type G.711A	~		
		Audio Input	Mode MIC	~		
		Audio Inpu	t Gain Level 8	~		
		Audio Outpu	t Gain Level 8	~		
		Audio ENV De	enoise Open	~		
			Save			

[Stream Type]: Choose stream type, include main stream, sub stream(third stream need customized).

[Frame Rate]: PAL/25fps, NTSC/30fps.

[GOP]: Set the interval value of two I frames.

[Bitrate(kb/s)]: Set the corresponding bit rate according to the selected resolution.

[Resolution]: Different cameras support multiple resolution types, and the corresponding resolution can be selected according to actual needs.

[Stream Mix Type]: Video stream & Complex stream optional. The video stream only refers to the video picture without sound, and the complex stream includes both sound and video.

[Encode Type]: H.265/H.264/ MJPEG optional.

[Encode Level]: High profile, main profile, base line corresponding to H.264 respectively

[Bitrate Type]: CBR & VBR & Fix QP optional.

[GOP Mode]:Normal P/DUAL P/SMART P optional.

[Audio Encode Type]: G.711A & G711U optional.

[Audio Input Mode]: MIC and line are optional, MIC input is built-in audio, and line input is external audio input.

[Audio Input Gain]: level1~level10 and mute are optional, the greater the level n, the greater the input volume

[Audio Output Gain]: level1~level10 and mute are optional, the greater the level n, the greater the output volume

[Audio ENV Denoise]: Effectively reduce the impact of surrounding noise and cause the degradation of sound quality

7.3.2 ROI

The user can set the most concerned and most interesting area in the video screen through the area of interest, and the camera will improve the video image quality of the corresponding area when encoding the video.



Click [Draw Area] button to frame the selected area in the video screen as needed.

The user can set up to 4 areas.

Click the [Enable] button and set to improve the [Quality]. The higher encoding quality, the better picture quality.

Note: This function is effective when using variable code stream

7.4 Image

7.4.1 Display

This page is image display parameters setting.

The video parameters such as "brightness", "contrast", "saturation", "grayscale" and "sharpness" of the camera can be adjusted according to the image effect.

review	Playback	I	_og	Conf	ïg	Logout				
System		Display	OSD V	ideo Mas	k ICR	AWB Weight	AE Weight			
NetWork			J							
AV				Channel	Channel (01 🗸				
Image										_
Safe		2021 FR -2	04790 BR 1	L:50:04 6-02kb			Mode	Normal	~	·
Event		1 1			Start -		Brightness	-		+ 128
Store				A Party of			Contrast	-	0	+ 128
Ptz							Grayscale	-	0	+ 128
Status					- pri	1	Saturation		0	+ 128
Local			-11	YAL AND		120	Sharpness	-	0	+ 128
			1413	1	2		Mirror	No	~	·
			A. A. A. M. A.				Flip	No	~	·
				A HAR	1/1/		Rotate	No	~	•
					1	i pe a me r	6 Flicker	Close	~	- -
		1843			- AND		WDR Mode	Digital WDR	. 🗸	1
			BLC	Close		~	WDR		0	+ 128
			Denoise	Middle		~	Shutter	Auto	~	•
			HLC	Close		~	Max Auto	Auto	~	1
			Gamma	User Defin	ne 4	\sim	Shutter			
			AE LEVEL	EV-0		\sim	Min Auto	Auto		1
			AE Offset	-	0	+ 128	Shuttor			
			ISO Max	Auto		~	Claw Chutter	Close		1
		F	ocus Mode	AutoFocu	S	\checkmark	Slow Shutter	Open		1
		Co	rrection =	0		+ 0	Anti Fog			
		5	Shading =	0		+ 0	AntiFog		9	+ 128
			Streng				Strength	A		ā
							AWB Mode	Auto	-	
							Red Gain	_	0	+ 128
							Green Gain	-	0	+ 128
							Blue Gain	-	0	+ 128
				Save		Default				

[Mirror]: The image is rotated 180° in the horizontal direction.

[Flip]: The image is rotated 180° in the vertical direction.

[Rotate]: Rotate the screen to select 90° & 270°.

[Flicker]: Close & 50Hz~240Hz optional. When irradiating the light from the lamp or the light from the lamp or the old-fashioned display screen, the screen will flicker, and the anti-flicker is to simulate flicker to avoid the flicker of the screen.

[WDR]: Wide dynamic is suitable for models with wide dynamic function. After opening the wide dynamic range, the user can adjust the level value to change the wide dynamic intensity according to actual needs.

[Shutter]: The electronic shutter time is generally between 1/25~1/10000 seconds. The electronic shutter of the camera is generally set to automatic electronic shutter mode, which can automatically adjust the shutter time according to the brightness of the environment to obtain a clear image.

[Max Auto Shutter]: 1/25~1/10000 seconds optional.

[Min Auto Shutter]: 1/25~1/10000 seconds optional.

[Slow Shutter]: Close & Auto & 1~1/20S optional.

[Anti Fog]: Set anti fogging function, improve the image quality when the density of fog up to a high value.

[Anti Fog Strength]: 1~128 optional.

[AWB Mode]: Auto & Indoor & Outdoor & ATW & Manual optional.

[Red Gain]/[Green Gain]/[Blue Gain]: Numerical adjustment is used to adjust the upper limit of the gain, and the default is automatic.

[BLC]: "Close" by default, the user can select the compensation area according to the location of the actual video scene that is too dark to avoid this area being too dark

[Denoise]: This option is used to adjust the level of noise reduction in the video. Noise reduction will also reduce picture details. Close & Lowest & Low & Middle & High & Highest optional.

[HLC]: Close & Open optional.

[Gamma]: Gamma can be considered as the brightness value, and the brightness value of different gamma modes is also different.

[AE Level]: When this camera detects an event according to event rule setting, this camera will change the Shutter and Gain state.

[AE offset]: 1~128 Optional.

[ISO Max]: Auto & 100~204800 optional.

[Focus Mode]: Auto Focus & Keep Focus & Manual Focus optional.

[Correction]: 0~255 optional.

[Shading strength]: 1~255 optional.

7.4.2 OSD

This page is setting display code stream information, week, date, time, display text and display color.

Among them, the automatic inversion is: white background and black border (stroke).



[Font size]: Small & Middle and big optional.

The user can drag the red box in the video to change the position of the time, date and text, and

click the [Save] button after dragging.

7.4.3 Video Mask

This page is setting video Mask parameters.



Check "Enable" to enable video masking function.

Area setting: Click **[Draw Area]**, click the left mouse button and drag the mouse in the screen, and then release the left mouse button to complete the drawing of an area.

Up to set 4 mask areas, click [Clear All] to clear all drawn areas.

7.4.4 ICR

This page is setting day & night switching mode, sensitive, fill light, light ctrl mode.

System Display OSD Video Mask ICR AWB Weight AE Weight NetWork AV AV Image Safe Mode Day Event Store Fill Light Infrared Ptz Status Local	Preview Pl	ayback	Log	Confi	3	Logout		HD-IP Camera
NetWork AV Channel Image Safe Mode Day Event Sensitive 5 Store Fill Light Infrared Ptz Light Ctrl Mode Save	System	Displa	y OSD	Video Masl	ICR	AWB Weight	AE Weight	
AV Channel Channel Image Image Safe Mode Day Event Sensitive 5 Store Fill Light Infrared Ptz Light Ctrl Mode Auto Status Save	NetWork							
Image Safe Mode Day ✓ Event Sensitive Store Fill Light Ptz Light Ctrl Mode Status Save	AV			Channel	Channel	01 🗸		
Safe Mode Day Event Day Store 5 Store Fill Light Infrared Ptz Light Ctrl Mode Status Local	Image							
Event Sensitive 5 Store Fill Light Infrared Ptz Light Ctrl Mode Auto Status Save	Safe			Mode [Day	~		
Store Fill Light Ptz Light Ctrl Mode Status Save	Event			Sensitive [5	~		
Ptz Light Ctrl Mode Auto Status Save	Store			Fill Light	Infrared	~		
Status Local	Ptz		Lig	ght Ctrl Mode	Auto	~		
Local	Status			Court				
	Local			Save				

[Mode]: Day & Night & Auto(outside) & Timer & Input Trigger & Auto(inside) optional.

In the Day mode, it is a color image and in the Night mode, it is a black & white image. Alarm input trigger: After selection, the corresponding trigger state can be selected as Day and Night. If the user's alarm input state is normally open and the alarm is triggered at night, then the camera saves the day state, when the alarm input is closed and triggered, the camera switches To the night state.

Note: The conversion of day-night mode "day-night" is generally set in the factory by default.

[Sensitive]: 1~10 optional.

[Fill Light]: Infrared & White optional.

[Light Ctrl Mode]: Auto & Keep-on & Keep-OFF optional.

7.4.5 AWB Weight

This page is setting AWB weight value.

Preview Play	back I	og	C	onfig		Log	out				HD	-IP C	Camer
System	Display	OSD	Video M	lask	ICR	AWB	Weight	AE We	ight				
NetWork AV			Chann	el CI	nannel 0	1	~						
Image													
Safe			Ope	en 🗆									
Event		Rov	/Column	0		1	2	3	4	5	6	7	
Store			0	0		0	0	0	0	0	0	0	
Ptz			1	0		0	0	0	0	0	0	0	
Status			2	0		0	0	0	0	0	0	0	
Local			2			0	0		0	0	0	0	
			3	0	_	0	0	0	0	0	0	0	
			4	0		0	0	0	0	0	0	0	
			5	0		0	0	0	0	0	0	0	
			6	0		0	0	0	0	0	0	0	
			7	0		0	0	0	0	0	0	0	
							I		1	1	1	1	l
				Set				Clear					

7.4.6 AE Weight

This page is setting AE weight value.

Preview	Playback	L	.og	с	onfig		Logout					HD-	IP Ca	mera
System		Display	OSD	Video M	lask	ICR	AWB W	eight	AE	Weight				
AV				Chann	nel Ch	annel 0	1	\mathbf{v}						
Image														
Safe				Op	en 🗆									
Event			Rov	/Column	0		1	2		3	4	5	6	7
Store				0	0		0	0		0	0	0	0	0
Ptz				1	0		0	0		0	0	0	0	0
Status				-	0		0	0		0	0	0	0	0
Local				2	0		U	0		0	0	0	0	0
				3	0		0	0		0	0	0	0	0
				4	0		0	0		0	0	0	0	0
				5	0		0	0		0	0	0	0	0
				6	0		0	0		0	0	0	0	0
				7	0		0	0		0	0	0	0	0
					Set				Clear	-				

7.5 Safe

7.5.1 User Manager

This page is setting user name and password.

Preview	Playback	Log	Config	Logout		HD	-IP Camera
System	U	ser Manager	Security Co	onfig			
NetWork		Add	Modify	Delete	1		
Image		No L	lser Name	Local Right	Remote Right	User Type	
Safe		1	admin	7	4095	Administrators	
Event							
Store							
Ptz							
Status							
Local							

7.5.2 Security Config

This page is setting for security configure.

Preview	Playback	Log	Config	Logout	HD-IP Camera
System	L	Jser Manager	Security Config		
NetWork					
AV		Enab	le Auto Lock 🗹		
Image		Login	Error Count 5		
Safe		Aut	to Lock Time 30	Minutes	
Event				7	
Store			14-11.		
Ptz					
Status					
Local					

7.6 Event

7.6.1 Motion Detect

This page is setting motion detect configure.

review	Playback	Log	Config	Log	jout		H	D-IP C
System	m	notion detect	hide detect	IO alarm	Alarm Out	Audio Alarm	Abnormal	alarm snap
NetWork	-							U
AV			Channel Ch	nannel 01	\sim			
Image		Δr		Timer	loint			
afe		1	<u> </u>	THE C	II Source	-		
Event		2 0 2 1 F R = 270 4	BR 384kb	1943		Draw A	Irea	
ore			1 Martin					
tz			1 Career	14		Clear A	AII .	
Status			147.4	-		Enable		
Local				発展が	Terring St.	Interva	1 5	S
		1 110	1 Street T	St la	7.48	Canaitin	2	~
			13	193		Sensitive	-	
		1.100		11/1				
				1/2/2/0100				
		And the	11/1	R. C		1		
			9 1 1	1 Estal	p 📲 t p a smar	a		

Tick the Detect switch to enable the motion detect function for network camera.

Click **[Draw Area]**, click the left mouse button in the screen and drag the mouse, then release the left mouse button to complete the drawing of an area, and up to 4 areas can be drawn in the screen. Click **[Clear All]** to clear all the drawn areas.

[Interval]: The interval between the start of the alarm and the end of the alarm.

[Sensitivity]: Sensitivity level is 1-5 can be set, 1 is the highest sensitivity, 5 is the lowest sensitivity;

Preview	Playback	Log		Config	L	ogout		H	D-IP Came
System		motion dete	ct	hide detect	IO alarn	Alarm Out	Audio Alarm	Abnormal	alarm snap
NetWork		-	Ц			.u.			
AV				Channel Ch	annel 01	~			
Image			Arei	a)	Timer	Joint			
Safe				0	an a	4	1		
Event		Week Al	IDay	Period 1		Period 2	Period 3	1	Period 4
Store		Sun		0:0-23	:59	:0 -23 :59	0:0-23	59 🗍 0 :	0 -23:59
Ptz		Mon		0:0-23	:59	:0 -23 :59	0:0-23	59 🗌 0 :	0 -23:59
Status		Tue		0:0-23	:59	:0 -23 :59	0:0-23	59 🗆 0 :	0 -23 :59
Local		Wed		0:0-23	:59	:0 -23 :59	0:0-23	59 🗆 0 :	0 -23 :59
		Thu		0:0-23	:59	:0 -23 :59	0:0-23	59 🗆 0 :	0 -23 :59
		Fri		0:0-23	:59	:0 -23 :59	0:0-23	59 🗌 0 :	0 -23:59
		Sat		0:0-23	:59	:0 -23 :59	0:0-23	59 🗆 0 :	0 -23:59
		All		0:0-23	:59	:0 -23 :59	0:0-23	59 🗌 0 :	0 -23:59
				Sa	ve				

[Timer]: You can check the arming time of the current motion detection. You can set the defense for the whole week or a certain day, and you can set the start and end time of 4 time periods for a day.

eview Playback	Log	Config	Log	gout		H	D-IP C
System	motion detect	hide detect	IO alarm	Alarm Out	Audio Alarm	Abnormal	alarm snap
NetWork	L		-				0
AV		Channel Ch	nannel 01	\sim			
Image	Are	a	Timer	loint			
Safe			- Internet				1
Event	Normal						
Store	Beep	🗌 Report 🗌 Ema	il				
Ptz							
Status	Recor	ď					
Local	Alarm	Out					
		shoot					
	DPTZ						

[Joint]: you can check the linkage mode setting.

Linkage methods include "conventional linkage", "linkage recording", "linkage alarm output", "linkage capture", and "linkage PTZ".

The corresponding alarm output channel can be selected for linkage alarm output.

After the related parameters are modified, you need to click the [Save] button to save the related settings.

7.6.2 Hide Detect

This page is setting hide detect parameters.



Check the "Detect switch" to enable mask detect function.

Click **[Draw Area]**, click the left mouse button in the screen and drag the mouse, then release the left mouse button to complete the drawing of an area, and up to 4 areas can be drawn in the screen. Click **[Clear All]** to clear all the drawn areas.

[Interval]: the interval between the start of the alarm and the end of the alarm.

[Sensitive]: Sensitivity level is 1-5 can be set, 1 is the highest sensitivity, 5 is the lowest sensitivity.

7.6.3 IO alarm

This page is setting IO alarm parameters.

Preview P	layback	Log	Config	Log	gout		H	D-IP Ca	mera
System	m	otion detect	hide detect	IO alarm	Alarm Out	Audio Alarm	Abnormal	alarm snap	
NetWork									
AV			Channel Ct	nannel 01	~				
Image		Ba		Timer	loint				
Safe		Da		Timer	Joint				
Event			Enable						
Store			IO Type Of	pen	\sim				
Ptz			Interval 0		S				
Status			Name						
Local			Sa	ive					

Tick "Switch" to turn on the IO alarm function.

[IO type]: open & close optional.

[Interval]: the interval between the start of the alarm and the end of the alarm.

[Name]: Input alarm name.

7.6.4 Alarm Out

This is setting alarm out parameters.

Preview	Playback	Log	Config	Log	gout		H	D-IP C	amera
System	m	otion detect	hide detect	IO alarm	Alarm Out	Audio Alarm	Abnormal	alarm snap	
NetWork									
AV			Channel Ch	nannel 01	~				
Image		BaseC	onfig						
Safe		1	- <u>-</u>						
Event			Enable 🗌						
Store			KeepTime 10		S				
Ptz			Name						
Status			Sa	ive					
Local									

Tick "Switch" to turn on the Alarm out function. [Keep Time]: Set alarm out keeping time.. [Name]: Input alarm out name.

7.6.5 Audio Alarm

This page is setting Audio Alarm parameters.

Preview	Playback	Log	Config	Log	gout		H	D-IP Came	era
System		motion detect	hide detect	IO alarm	Alarm Out	Audio Alarm	Abnormal	alarm snap	
NetWork									
AV			Channel Ct	nannel 01	\sim				
Image		Ba		Timer	loint				
Safe			se [Timer	Joint				
Event			Enable 🗌						
Store			Debug 🗌						
Ptz			Sensitive 3		\sim				
Status			Interval 15		S				
Local			Thresh 68						
			Sa	ive					

Tick "Switch" to turn on the Audio Alarm function.

[Debug]: Tick "Switch" to turn on the debug function.

[Interval]: the interval between the start of the alarm and the end of the alarm

7.6.6 Abnormal

This page is setting abnormal parameters.

System motion detect hide detect IO alarm Alarm Out Audio Alarm Abnormal alarm snap NetWork AV Type No Disk V Image Safe Normal Vormal	Preview Playback	Log	Config	Log	gout		H	D-IP Came
Store Ptz Status Local Alarm Out Snapshot	System NetWork AV Image Safe Event Store Ptz Status Local	Normal Beep Record I Alarm Snaps	hide detect Type No Report Emai d Out shot	IO alarm	Alarm Out	Audio Alarm	Abnormal	alarm snap

[Type]: No Disk & Disk Full & Disk Error & Network Down & IP Conflict optional.

Linkage methods include "conventional linkage ", "linkage recording", "linkage alarm output", "linkage capture", and "linkage PTZ".

The corresponding alarm output channel can be selected for linkage alarm output.

After the related parameters are modified, you need to click the [Save] button to save the related settings.

7.6.7 alarm snap

This page is setting alarm snap parameters.

Preview	Playback	Log	Config	Lo	gout		H	D-IP Came	ra
System		motion detect	hide detect	IO alarm	Alarm Out	Audio Alarm	Abnormal	alarm snap	
NetWork			4	4			0	L	
AV			Enable 🗆						
Image			Interval 1		(0~255)S			
Safe			Quality 🛑		0 80				
Event			Count 1						
Store			Delay 0		(0~255)s			
Ptz			FTP Upload						
Status		F							
Local			Sa	ive					

Alarm snapshot is the linkage alarm capture which suit for motion detection, occlusion alarm, IO alarm, abnormality and other alarms. Image quality of the capture image numbers can be setting. If you want to upload FTP and EMAIL, should enable the button, need click [Save] button to save modify parameters .

7.7 Store

7.7.1 Record

This Page is setting Record parameters.

Preview	Playback	Log	Config	Logout	HD-IP Camera
System	Re	ord Disk T	ime Snap		
NetWork	1	U U	-		
AV			Channel Channel	01 🗸	
Image					
Safe		St	reamType Main	\sim	
Event		Pre Recod	e(Second) 3		
Store		Delay Recor	d(Second) 0		
Ptz		Record Pack Tim	ne(Minute) 5		
Status		Reco	de Stream Complex	Stream 🗸	
Local		Enab	le Recoder		
			Save		

Check "Enable Recording Plan" to start the recording plan and return to the recording time setting page.

The recording time can be set for the whole week or a certain day for recording. For a day, the start and end time of 4 time periods can be set

[Stream type]: main stream and sub stream can be optional

[Pre-recording(Second)] : After the SD card receives the alarm trigger signal, it adds a period of time before the alarm signal is received to the alarm recording file.

[Delay Record(Second)]: Set time to record after receiving the alarm signal.

Eventually, the recording before and after the alarm signal will be made into a file to form an alarm recording file. This can continuously reflect the continuous recording before and after the alarm signal occurs.

[Record Pack Time(Minute)]: Set the length of a video file.

[Recode Stream]: video stream (no sound) or composite stream (with sound).

7.7.2 Disk

This page is setting Disk parameters.

Preview	Playback		Log	Config	Logout				HD-IP	Camera
System		Record	Disk	Time Snap						
AV			Di	sk						
Image				No Total(M)	Free(M)	Backup	State	Туре	FileSystem	
Safe										
Event										
Store										
Ptz				Format						
Status										
Local										

Serial number: display disk serial number.

Total capacity: display total capacity.

Remaining capacity: display remaining space.

Hard disk status: display whether the hard disk is recording, divided into "in use" and "not recording" Hard disk type: SD card/SATA (serial hard disk)

File system format: EXT, FAT32, etc.

Formatting: After initializing the disk, all files on the disk will be cleared after formatting

7.7.3 Time Snap

This page is setting time snap parameters.

Preview	Playback	Log	Config	Logout	HD-IP Camera
System		Record Disk	Time Snap		
AV			Enable 🗌		
Image			Interval 5	S	
Safe			Qulity	0 80	
Event			FTP 🗆		
Store			All Day		
Ptz			Period 1 🔲 🛛	: 0 - 23 : 59	
Status			Period 2 🔲 🛛	: 0 - 23 : 59	
Local			Period 3 🔲 🛛) : 0 - 23 : 59	
			Period 4 🔲 🛛) : 0 - 23 : 59	
			Sav	e	

Checking "Enable" turn to timing snapshot function.

The snapshot image saved in the SD card or disk, and save path "File Management> Query Device Snapshots" in the video surveillance client.

[Interval]: capture a picture every few seconds

[Quality]: the higher the value, the better the quality

[FTP]: Check setting on FTP part.

Select the capture time period, you can capture all day, or you can set 4 times

7.8 PTZ

This page is setting PTZ parameters. It is up to camera function.

Preview	Playback	Log Cor	nfig Logout	HD-IP Camera
System	PTZ			
NetWork		L	0.0	
AV		Channel	Channel 01 V	
Image				
Safe		Serial	2	
Event		PTZ Addr	1	
Store		Protol	pelcoD 🗸	
Ptz		BaudRate(bps)	4800 🗸	
Status		DataBit	8 🗸	
Local		StopBit	1 🗸	
		FlowType	None 🗸	
		Parity	None 🗸	
		ByPass Mode	No ByPass 🗸	
	**(Change ByPass Mode E	ffect After Restart Dev	ice
			Save	

7.9 Status

7.9.1 HardWare

On this page, you can query the alarm input, alarm output status, and network card status.

Preview P	layback Lo	g	Config	Logout		HD-IP Camera
System	HardWare	Recode	Channel	Bitrate		
NetWork						
AV		Device	State Norm	al		
Image		Local Display	State Norm	al]	
Safe		Chip Tempe	rature 0			
Event		Alarm O	ut State		_	
Store		Cha	annel		State	1
Ptz			1	Closed		
Status		Alarm II	1 State			1
Local		Cha	annel		State	
		1				
		NetCard	State			
			Vo		State	
			1	Link		
			Refres	h		

7.9.2 Recode

On this page, you can query the disk status, total capacity and remaining capacity, and channel recording status of the storage device.

Preview	Playback	Log		Config	Logout		HD-IP Camera
System		HardWare	Recode	Channel	Bitrate		
NetWork							
AV			Device				
Image			No	Total(M)	Free(M)	Disk State	
Safe			Channel	Record St	ate		
Event			Cha	annel		State	
Store				1	No Record		
Ptz				Refres	h		
Status							
Local							

7.9.3 Channel

On this page, you can query the signal status, hardware status, and audio input status of all channels under the device.

System	HardWare						
		Recode	Channel	Bitrate			
NetWork			1	U			~
AV			Sign	al State	HW State	Audio State]
Image		1	Normal		Normal	Unuse	
Safe			Refres	h			
Event							
Store							
Ptz							
Status							
Local							

7.9.4 Bitrate

On this page, you can view the size of main stream, sub stream, and third stream empty now.

Preview	Playback	Log		Config	Log	gout		HD-IP Camera
System NetWork		HardWare	Recode	Channel	Bitrate			
AV			Bitrate		□ Au	uto Refresh		
Image			Channe	I Main	Stream	Second Stream	Third Stream (kbps)	
Safe			1	4936	(0)07	719	0	
Event				Refres	h	Second and a second		1
Store				rteires				
Ptz								
Status								
Local								

7.10 Local

This page is setting file saving path parameters.

Preview	Playback	Log	Con	fig	Logout				
System NetWork		Local Config							
AV		Active	eX Version	v1.0.14	4				
Image		Local Re	ecord Path	C:\Users\Administrator\AppData\Local\H265Active\LocalRecord\					
Safe		Local Pi	cture Path	$\label{eq:c:Users} C: \label{eq:c:Users} Administrator \arrow Data \black Local \black H265 \arrow Local \black Capture \black Capture \black Local \black Capture \bl$					
Event		Download Re	ecord Path	$\label{eq:c:Users} C: \label{eq:c:Users} Administrator \appData \Local \H265 \Active \Download \Recconstruction \Barbox \Bar$					
Store		Download Pie	cture Path	$\label{eq:c:Users} C: \label{eq:c:Users} Administrator \ AppData \ Local \ H265 \ Active \ Download \ Picture \ AppData \ Active \ Activ$					
Ptz Status		Tips: Use Administator to excute the browser and to							
Local			Mod	ify path	ח!				
				Save					

Note: To modify the save path, you need to run as administrator account.

8. Logout

Logout the login page.

9. Al Functions(Support Module)

9.1 Video Diagnosis

Video diagnosis: "abnormal brightness", "abnormal sharpness", "abnormal color", "scene change, PIR human detect".

Abnormal brightness: including the video picture is too bright and too dark;

Abnormal sharpness: the main manifestation is blurry picture;

Color abnormality: detect the color attribute of the screen, and judge whether the screen is color cast;

Scene change, human detect: detect whether the overall content of the screen has been changed;

9.1.1 Abnormal Brightness

Check the "Enable" button, select [Brightness Abnormal], and set the sensitivity and arming time. When the real-time image is too bright or too dark, an alarm will be generated, and the log information will generate an alarm of "Video Diagnosis-Brightness Abnormal Alarm Start" Record.



Video brightness normal

Video brightness abnormal

9.1.2 Sharpness Abnormal

Check "Enable" button, select [Sharpness Abnormality], set the sensitivity and arming time. When the real-time picture is blurred, an alarm will be generated, and an alarm record of "Video Diagnosis-Sharpness Abnormal Alarm Start" will be generated in the log information.



Video sharpness normal

Video sharpness abnormal

9.1.3 Color Abnormal

Check "Enable" button, select [Color Abnormal], and set the sensitivity and arming time. When the real-time screen has a color cast, an alarm will be generated, and an alarm record of "Video Diagnosis-Color Abnormal Alarm Start" will be generated in the log information



Video color normal

Video color abnormal

9.1.4 Scene Change

Check the "Enable" button, select [Scene Change], and set the sensitivity and arming time. When the real-time screen appears that the overall content is changed, an alarm will be generated, and an alarm record of "Video Diagnosis-Scene Change Alarm Start" will be generated in the log information



Normal surveillance scene

9.2 Cross line, Warning Area, Object leave, Object lost

Click "Config→IntelligentAnalysis→Cross line, Warning zone, Object leave ,Object lost", choose "enable" turn on this function

Set the time strategy and usage scenarios according to the actual situation (the scene is divided into indoor/outdoor) as shown in the figure below:

Single cross line: detect whether there is a target crossing the virtual detection line, support one-way and two-way crossing detection;

Warning zone: detect whether there is a target entering or leaving the designated area through the edge of the designated area;

Object leave: detect whether there are objects left in the designated detection area;

Object lost: detect whether any objects have been moved out of the designated detection area

9.2.1 Single cross line

Crossing direction: two-way, from right to left (from bottom to top), from left to right (from top to

Tramping surveillance scene

bottom) optional

Select to check "Enable", click "Modify Area", you can drag line position in the left image, click OK to set successfully.

If the crossing direction is set from left to right, the direction of the tripwire is shown in the figure. When an object moves from left to right through the tripwire intrusion, a real-time alarm will occur, and the image will frame the invading object.



Single cross line

Cross line alarm

Note:

When the crossing direction is set from left to right, only objects invading from the left to the right will trigger alarm. If a person comes out from right to left, the alarm will not be triggered.

If the crossing direction is set from right to left, the direction of the tripwire is as shown in the figure. When an object moves from right to left through the tripwire intrusion, a real-time alarm will occur, and the image will frame the invading object.



Cross line alarm2

Cross line alarm2

If the crossing direction is set to bidirectional, the direction of the tripwire is as shown in the figure. When an object touches the tripwire, whether it is from left to right or from right to left, a real-time alarm will occur, and the image will draw the intruding object frame.

9.2.2 Warning Area



Polygon: The default is "quadrilateral", you can choose "triangle", "quadrilateral", "pentagon", "hexagon", "heptagon", and "octagon".

Warning alarm mode:

- 1. Intrusion: when object touch warming demarcation area, alarm will be trigger
- 2. Entry: alarm trigger when an object entry warning area
- 3. Leaving: alarm trigger when an object comes out of the warning area

Check "Enable", click "Modify Area", drag the trip wire position in the image on the left, and click OK to set successfully.

9.2.3 Object Leave

Rule type: select "object leave"

Polygon: The default is "quadrilateral", you can choose "triangle", "quadrilateral", "pentagon", "hexagon", "heptagon", and "octagon".

Select to check "Enable", click "Modify Area", you can drag the trip wire position in the left image, click OK to set successfully.



Object leave alarm

Object leave alarm2

At the same time, if the item stays for a period of time, and then the item is taken away, the object leave alarm will also be trigger, because the system essentially cannot distinguish whether the item is taken away or leave (the system will automatically upload a picture of the designated area, When it is determined that the picture in the current area is different from the previous one, the system will trigger an alarm.

9.2.4 Object Lost

Detect type: "Object lost"

Polygon: The default "quadrilateral", you can choose "triangle", "quadrilateral", "pentagon", "hexagon", "heptagon", and "octagon".

Select "Enable", click "Modify Area", you can drag the trip wire position in the left image, click OK to set successful

Note: object lost detect can be a large area, but the object item should be in our drawing polygon. Since object detect area is too large, it is hard to detect it

2019-03-12 18:22:36 2019-0



Object Lost

Object lost alarm

10. Appendix

10.1 Upgrading the Firmware

If you suspect a problem is being caused by incorrect configuration or someother minor problem, consult the troubleshooting guide below.

Firmware is software that determines the functionality of the network camera. One of your first actions when troubleshooting a problem should be to check the current firmware. The latest version may contain a correction that fixes your particular problem. The current firmware version in your camera is displayed on the Basic Configuration or About. For the latest firmware of the camera, please contact with your product administrator.

Detailed instructions on how to perform the upgrade process are provided with each new release. See also the Maintenancen/ Upgrade for more information.

10.2 General Troubleshooting

Suggests how to remedy them: **Symptom** \rightarrow **Possible Causes or Corrective Actions**

1. The camera cannot be accessed by some clients.

If using a proxy server, try disabling the proxy setting in your browser.

Check all cabling and connectors.

2. The camera works locally, but not externally.

Check if there are firewall settings that need to be adjusted. Check if there are router settings that need to be configured.

3. Poor or intermittent network connection.

If using a network switch, check that the port on that device uses the same setting for the network connection type (speed/duplex).

4. The camera cannot be accessed via a host name.

Check that the host name and DNS server settings are correct.

5. Not possible to log in.

When HTTPS is enabled, ensure that the correct protocol (HTTP or HTTPS) is used. When attempting to log in, you may need to manually type in http or https in the browser's address bar.

6. No image using Refresh and/or slow updating of images.

If images are very complex, try limiting the number of clients accessing the camera. Check the Video & Image setting.

8. Blurred images.

Refocus the camera.

9. Poor image quality.

Increased lighting can often improve image quality. Check that there is sufficient lighting at the monitored location. Check all image and lighting settings.

10. Rolling dark bands or flickering in image.

Try adjusting the Exposure Control setting under AE and AWB part.

11. H.264/H.265 not displayed in the client.

Check that the correct network interface is selected in the Video & Image/Stream.

12. Multicast H.264/H.265 not displayed in the client.

Check with your network administrator that the multicast addresses used by the camera are valid

for your network. Check that the Enable multicast checkbox are enabled in the System/Network/RTP tab. Checks with your network administrator to see if there is a firewall preventing viewing.

13. Multicast H.264/H.265 only accessible by local clients.

Check if your router supports multicasting, or if the router settings between the client and the server need to be configured. The TTL value may need to beincreased.

Modify the settings for your graphics adapter. Please see the adapter's documentation for more information.

15. Poor audio quality.

Too many <u>users/clients</u> connected to the camera may affect the sound quality adversely. Try limiting the number of clients allowed to connect.

16. Distorted audio.

Check that the correct <u>Audio Input source</u> is selected. Select Microphone for a connected external microphone. Select Line for a connected line in source.

NOTE

If you cannot find the help you require, please see the User's Manual, or contact with your network administrator.